

# vSet<sup>®</sup> vSet Select Fittings Kit (Kinze)

731186

## Parts List

- **731182 Vac Hose Meter Fitting** (Qty. 1)
- **731177 Row Unit Hose Cap** (Qty. 1)
- **730308 1.5" Elbow** (Qty. 1)

The 731186 vSet Fittings Kit is used for new installs on Kinze EdgeVac planters with the vacuum inlet directly under the main vacuum tube. This may not be required on each row.



## Step 1

Remove the OEM row unit flex hose.

## Step 2

Cut the 1.5" row unit hose. Some rows may require different lengths. Measure to be sure the new fitting will fit correctly onto the row.

## Step 3

Thread the 731182 vacuum hose meter fitting onto the 1.5" row unit hose. This fitting uses left handed threads to attach. Turn counterclockwise to tighten. You will also need to tighten the clamps on the elbow on the manifold.

## Step 4

Carefully route the row unit hose. The new 135 degree fitting will require the hose to be routed above the cross member bracket. Adjust the 731182 meter fitting leftward to transition the row unit hose as shown at right.



Precision Planting<sup>®</sup>

**Step 5**

Route the row unit hose on the pusher row units, if applicable. Angle the meter fitting to transition the row unit hose into the vacuum supply.

**Step 6**

Use the 731177 row unit hose cap to manually disable planter rows.

