

EdgeVac Elbow Fitting Kit

Parts List

- **731104 Vac Hose Meter Fitting** (Qty. 1)
- **730224 Row Unit Hose Cap** (Qty. 1)
- **730308 1.5" Fernco Elbow** (Qty.1)

The 731176 vSet 2 Fittings Kit is used for new installs on Kinze EdgeVac planters. You will use this kit for EdgeVac planters with the vacuum inlet pointed downward. This may not be needed on each row of the planter.

**Step 1**

Remove the OEM Flex Hose.

Step 2

Cut the 1.5" row unit hose to remove the existing meter fitting. Some rows may require additional length to be removed. Make sure you have measured to be sure the new fitting will fit correctly onto the row.

Step 3

Thread the 731104 Vacuum Hose Meter Fitting into the existing row unit hose. This fitting uses left handed threads to attach. Turn the fitting counter clockwise to tighten. See below.

Step 4

Carefully route the row unit hose. The new 135 degree fitting will require the hose to be routed above the cross member bracket. Adjust the 731104 meter fitting leftward to transition the row unit hose as shown below.



Precision Planting®

Step 5

Route the row unit hose on the pusher row units, if applicable. Angle the meter fitting to transition the row unit hose into the vacuum supply.

**Step 6**

Use the 730224 Row Unit Hose Cap to manually disable planter rows.

