

EdgeVac Straight Fitting Kit

Parts List

- **731104 Vac Hose Meter Fitting** (Qty. 1)
- **730224 Row Unit Hose Cap** (Qty. 1)
- **731101 1.5" Fernco Flexible Coupler** (Qty.1)

The 731175 vSet 2 Fittings Kit is used for new installs on Kinze EdgeVac planters. You will use this kit when the EdgeVac ductwork uses a straight vacuum inlet on the vacuum tube.

**Step 1**

Remove the OEM row unit hose. If you are installing on a Kinze 3600 planter you will leave the plastic ducting in place.

Step 2

Thread the 731104 Vacuum Hose Meter Fitting into the existing row unit hose. This fitting uses left handed threads to attach. Turn the fitting counter clockwise to tighten. See below.

**Step 3**

Carefully route the row unit hose. The new 135 degree fitting will require the hose to be routed above the cross member bracket. Adjust the 731104 meter fitting leftward to transition the row unit hose as shown below.



Precision Planting®

EdgeVac Straight Fitting Kit

Step 4

Route the row unit hose on the pusher row units, if applicable. Angle the meter fitting to transition the row unit hose into the vacuum supply.

**Step 5**

Use the 730224 Row Unit Hose Cap to manually disable planter rows.

