

Great Plains YP DeltaForce Drilling Template 712529

On some Great Plains YP versions, you are not able to bolt the upper Delta Force cylinder bracket (712522) directly on the W-bracket because the holes are not present, so you will need drilling those holes.

Instructions:

Place the drilling template on the side of the W-bracket using the existing bolts. Then use the transfer punch to mark the location of the hole. Remove the drilling template and drill the holes with the 13/32" drill bit provided in the kit (or a 10.3mm or 10.5mm).

