

vSet®

Installation Instructions for JD 7200/17XX Wedge Adapter Standard Hopper

Parts included in this kit:

- Hex Nut, M8 x 1.25 Stl Zn (40307)
- Washer, M8 Stl Zn (40357)
- Wedge Adapter (730259)

Installing Wedge Adapter

The 7200/17XX hopper does not have a flat surface or correctly located bolt hole to install vSet. To make your hopper compatible with vSet, you will need to install the Wedge Adapter (730259). The wedge is first secured onto the hopper with the lower bolt using the supplied nut and washer (see arrow). After this is installed you can now attach your vSet meter to the hopper.



Wedge Adapter Installed



Completed installation

Questions? Visit www.precisionplanting.com or call us at 309-925-5050.

