

Precision Meter

Kinze 4900 Boot Modification for Precision Meter Compatibility

The Precision Meter has one more nut and bolt in the housing than the Kinze 4900 finger meter (See Illustration A). In order to use the Kinze boot with the Precision Meter, you will need to remove some of the lip of the Kinze boot with a razor blade so that the boot will fit on the meter (See Illustration B). Remove enough of the lip to install on the Precision Meter (See Illustration C).

Additional Bolt &
Nut that Interferes
with Kinze 4900
Boot



Illustration A

Area of Lip
Requiring
Modification



Illustration B

Modified
Kinze Boot
Installed on
Precision
Meter



Illustration C