

vSet Bulk Fill Extension Kit

Parts List

- **730448 1.25" Bulk Fill Hose** (Qty. 8')
- **730446 Hose Clamp** (Qty. 4)
- **730432 1.25" Bulk Fill Connector** (Qty. 4)
- **720276 O-Ring** (Qty. 4)
- **730439 Bulk Fill Cap** (Qty. 4)

The 730447 **vSet Bulk Fill Extension Kit** is designed to provide additional seed delivery hose length to Kinze Pusher row units.

Installation requires the 730045 Kinze Pusher Row Unit Inlet Elbow.

Rows not needing this bulk fill extension kit will require 730471 **Kinze Pusher Row Unit Shim**.

Step 1

Remove the Kinze fill tube shim (if applicable). Use a flathead screwdriver to gently remove the shim.



Step 2

Cut to remove the OEM connectors from the existing 1" hose.

Step 3

Measure from the OEM Bulk Fill lines to the row units to determine the additional length needed. Cut the needed length from the 730448 bulk fill hose. Row units needing extensions are typically located on either side of the drive system of the planter.

Step 4

Attach the 730432 Bulk Fill Connector to the cut row unit hose. Liquid soap may be used as a lubricant to properly seat the hose past the second barb on the connector.



Step 5

Slide the 730446 Hose Clamp over the row unit hose and insert the cut end into the OEM hose. Tighten the clamp. Allow approximately 3" of hose overlap to ensure a solid splice.



Step 6

Connect the 730432 Bulk Fill Connector to the 730045 Kinze Pusher Row Unit Inlet Elbow. Be sure that there is a 720276 O-Ring installed in the connector to guarantee a proper vacuum seal.



Step 7

Install the 730439 Bulk Fill Cap by removing the connector from the fill tube, inserting the cap, and reinstalling the connector. This is used to shut off rows that are not planting.



Installation Complete

