



Kuhn Lift Switch and SRM Installation

 Precision Planting®

Kuhn SRM and Lift Switch Installation

712123 — SRM Mount Kit		
Qty	Part Number	Part Description
1	712127	SRM Mounting Bracket
1	712128	Hardware Kit

Installing the SRM

Install the SRM using the bracket and hardware as shown in the image below.



712251 – Lift Switch Kit		
Qty	Part Number	Part Description
2	63126	Cable Tie
1	712252	Bracket
1	712253	Hardware Kit
1	726760	Lift Switch

To install the lift switch, install the bracket as shown using the supplied bracket and hardware kit.

