

The following illustrations are guides that show where to plug in a lift switch and when a planter harness is needed vs being able to plug straight into the SRM architecture. Use these for ordering and installation processes.

Lift Switch

Lift Switch Guide					
Lift Switch	20/20	AirForce	RowFlow	DeltaForce	Vdrive
Push Button	N/A	RUM	RFM	SRM	SRM
Whisker	N/A		RFM	PDM	PDM
Rotary	N/A		RFM	PDM	PDM
System			Connect		
AirForce/RowFlow			RFM		
DeltaForce/RowFlow			RFM		
DeltaForce/Vdrive-			SRM/PDM		

Seed Monitoring

Seeding	SRM	Planter Harness	SmartConnector Needed
vDrive	X		
RowFlow (Hydraulic Motor)	X		
RowFlow (Ground Drive)		X	X
20/20 No RowFlow		X	X
OEM controls Seeding		X	X

* Assuming DeltaForce is installed