

White 9000 RUM and SRM Installation

Installing a Row Unit Module (RUM) or Single Row Module (SRM) on a White 9000-series row unit requires drilling a hole to mount the module. No additional or unique parts are otherwise necessary.

Installation Instructions:

- 1) Drill a 5/16" hole 5 1/2" from the base plate and 1 5/8" from the back on the left hand post. (see image at right)
- 2) Prepare the RUM or SRM for mounting. On the back of the RUM, cut off the tabs labeled "XP". On the back of the SRM, cut off the bottom two tabs.
- 3) Install RUM/SRM upside down (as seen below).

Location of Hole in Post



RUM installed on White 9000-series row unit



SRM installed on White 9000-series row unit