

Tech Bulletin: SRM System Harness Update Installation Instructions

August 1, 2014

DeltaForce®

2014 vDrive and DeltaForce customers will receive two harness updates for 2015: a CAN Extension Harness for each planter and a SRM Row Fuse Adapter for each row. Install as described below.

CAN Extension Harness Installation

The appropriate CAN Extension length will be provided based on the Tractor Power Extension length originally ordered.

Step 1: Connect the 4-pin Deutsch connector on the 729149 SRM CAN Tractor Harness to the 4-pin Deutsch on the provided CAN Extension.

Step 2: Route the CAN Extension along the existing Tractor Power Extension Harness.

Step 3: Connect the new CAN Extension to the 4-pin Deutsch connector on the PDM.

Tractor Power Extension with Corresponding CAN Extension			
Tractor Power Extensions		CAN Extension	
Length	Part Number	Length	Part Number
5'	729170	5'	729140
15'	729171	15'	729142
25'	729172	30'	729144
35'	729173	45'	729145
45'	729174	60'	729146
55'	729175	60'	729146
65'	729176	60'	729146

SRM Row Fuse Adapter (729136)

Step 1: Disconnect the 8-pin Deutsch connector between the backbone harness and the SRM row harness. See Illustration 1.

Step 2: Install the fuse adapter in-line between the backbone harness and the SRM row harness. See Illustration 2.



Illustration 1



Illustration 2