

vDrive Insecticide High Flow Meter - John Deere XP Installation

Description of problem: High Flow vDrive Insecticide funnel (732030) interferes with rear insecticide support on John Deere XP row unit. See photos below for details on interference between the funnel and support.



Resolution: Using a cutting disc, trim the support bracket along the dashed line illustrated below:



Cut along red dashed lines.



The removed section will allow clearance for the installation of the meter with funnel installed.