

Parts List

- **731104 Vac Hose Meter Fitting** (Qty. 2)
- **730224 Row Unit Hose Cap** (Qty. 1)
- **1.5" Row Unit Hose** not included

The 731183 vSet 2 Fittings Kit is used for newly installed vacuum systems. You will install 1.5" row unit hose to complete the install.

**Step 1**

Cut the 1.5" row unit hose to length. Some rows may require additional length depending on where the hole was drilled on the main vacuum tube. Do not cut the row unit hose too short. A general starting point is 4' per row.

Step 2

Thread the 731104 Vacuum Hose Meter Fitting into the existing row unit hose. This fitting uses left handed threads to attach. Turn the fitting counter clockwise to tighten.



Step 3

Carefully route the row unit hose. The new 135 degree fitting will require the hose to be routed above the cross member bracket.

**Step 4**

Use the 730224 Row Unit Hose Cap to manually disable planter rows.

