

Parts List

- 731104 Vacuum Hose Fitting (Qty. 1)
- 731193 AGCO Row Unit Hose Adapter (Qty. 1)
- 731177 Row Unit Hose Fitting Cap (Qty. 1)
- 731278 2"x1.5" Flexible Coupler (Qty. 1)
- 730147 #10 Self Tapping Screws (Qty. 2)

Note: 1.5" Row Unit Hose not included

The 731192 vSet Fittings Kit is used to install vSet 2 on White 8000 and 9000 planters.



Step 1

Remove the AGCO row unit hose and meter fittings.



Step 2

Insert the AGCO Row Unit Hose Adapter (731193) into the 2" fitting. Some older planters may have warped plastic that is susceptible to leaking. Use the provided #10 screws to properly seal the connection. Sealant may be necessary if the plastic is extremely loose.



Step 3

Clamp the 2" x 1.5" Flexible Coupler onto the AGCO Row Unit Hose Adapter (731193). Do NOT over tighten the clamps to bend the plastic.

**Step 4**

Cut the 1.5" row unit hose to length. The length required may vary from row to row. Most rows will require about 4' of hose. Insert the hose into the 2" x 1.5" Flexible Coupler.

**Step 5**

Thread the 731104 Vacuum Hose Meter Fitting onto the row unit hose. This fitting uses left handed threads to attach. Turn the fitting counter clockwise to tighten.

**Step 6**

Use the 731177 Row Unit Hose Fitting Cap to manually disable planter rows.

