

FurrowForce®


FurrowForce Parts Manual

Precision Planting®


Table of Contents

200145 FurrowForce Lock-up Detent Pin.....	3
200147 Depth Linkage Clevis Pin.....	4
200215 Locking Cotter Pin	5
726101 Airbag	6
756001 FurrowForce Assembly Upper Frame - Gray.....	7
756016 FurrowForce Assembly Upper Frame - Green.....	8
756032 Stitch Wheel Assembly	9
756039 FurrowForce Swingarm Sleeve Bearing	10
756052 FurrowForce Wheel Hub Assembly Kit.....	11
756066 Stitch Wheel	12
756067 Stitch Wheel Spacer Plate	13
756068 Stitch Wheel Backing Plate.....	14
756081 FurrowForce Assembly Upper Frame - Red	15
756085 First Stage Wheel Bearing Hub.....	16
756086 First Stage Notched Wheel - Left.....	17
756087 First Stage Notched Wheel - Right.....	18
756093 Stitch Wheel Bearing Dust Cap.....	19
756094 Stitch Wheel Bearing Assembly.....	20
756095 Depth Link Pad Assembly.....	21
756096 Depth Link Handle Assembly	22
756098 Depth Link Yoke Assembly	23
756155 Depth Link Shim Gauge.....	24
756157 First Stage Wheel Hub with Bearing.....	25
756158 First Stage Wheel Hardware Kit.....	26
756177 Five Hole Swingarm Assembly - Gray	27
756178 Five Hole Swingarm Assembly - Green.....	28
756179 Five Hole Swingarm Assembly - Red.....	29
756194 Pivot Bushing	30
756195 Depth Linkage Spacer	31
756202 Belleville Washer.....	32
756224 Tail Frame - Gray	33
756225 Tail Frame - Green.....	34
756226 Tail Frame - Red.....	35
756316 PTC Stem.....	36
756237 First Stage Wheel Bearing.....	37

200145 FurrowForce Lock-up Detent Pin




200147 Depth Linkage Clevis Pin




Item No.	Part Number	Part Name	QTY	Remarks
1	200147	PIN		7/16" x 1.5"

200215 Locking Cotter Pin




Item No.	Part Number	Part Name	QTY	Remarks
1	200215	PIN		Holds Depth Linkage Clevis Pin

726101 Airbag




Item No.	Part Number	Part Name	QTY	Remarks
1	726101	Spring		

756001 FurrowForce Assembly Upper Frame - Gray




Item No.	Part Number	Part Name	QTY	Remarks
1	756001	FRAME		Gray

756016 FurrowForce Assembly Upper Frame - Green




Item No.	Part Number	Part Name	QTY	Remarks
1	756016	FRAME		Green

756032 Stitch Wheel Assembly




Item No.	Part Number	Part Name	QTY	Remarks
1	0129156	NUT	6	
2	756066	WHEEL	1	
3	756067	PLATE	1	
4	756068	PLATE ASM	1	
5	756094	BEARING ASM	1	

756039 FurrowForce Swingarm Sleeve Bearing




Item No.	Part Number	Part Name	QTY	Remarks
1	756039	BEARING		Used in front swingarm pivot

756052 FurrowForce Wheel Hub Assembly Kit




756066 Stitch Wheel




Item No.	Part Number	Part Name	QTY	Remarks
1	756066	WHEEL		

756067 Stitch Wheel Spacer Plate




Item No.	Part Number	Part Name	QTY	Remarks
1	756067	PLATE		

756068 Stitch Wheel Backing Plate




Item No.	Part Number	Part Name	QTY	Remarks
1	756068	PLATE ASM		

756081 FurrowForce Assembly Upper Frame - Red




Item No.	Part Number	Part Name	QTY	Remarks
1	756081	FRAME		CIH Red

756085 First Stage Wheel Bearing Hub




Item No.	Part Number	Part Name	QTY	Remarks
1	756085	HUB		

756086 First Stage Notched Wheel - Left




Item No.	Part Number	Part Name	QTY	Remarks
1	756086	WHEEL		

756087 First Stage Notched Wheel - Right




Item No.	Part Number	Part Name	QTY	Remarks
1	756087	WHEEL		

756093 Stitch Wheel Bearing Dust Cap




Item No.	Part Number	Part Name	QTY	Remarks
1	756093	DUST CAP		

756094 Stitch Wheel Bearing Assembly




Item No.	Part Number	Part Name	QTY	Remarks
1	756094	BEARING ASM		

756095 Depth Link Pad Assembly




Item No.	Part Number	Part Name	QTY	Remarks
1	756095	PAD ASM		

756096 Depth Link Handle Assembly




Item No.	Part Number	Part Name	QTY	Remarks
1	756096	HANDLE ASM		

756098 Depth Link Yoke Assembly




Item No.	Part Number	Part Name	QTY	Remarks
1	756098	YOKE ASM		

756155 Depth Link Shim Gauge




Item No.	Part Number	Part Name	QTY	Remarks
1	756155	GAUGE		Used for setting the proper clearance of the FurrowForce sensor

756157 First Stage Wheel Hub with Bearing




Item No.	Part Number	Part Name	QTY	Remarks
1	756085	HUB	1	
2	756237	BEARING	1	

756158 First Stage Wheel Hardware Kit




Item No.	Part Number	Part Name	QTY	Remarks
1	37341	SERRATED FLANGE NUT	8	3/8" -16, Zinc
2	38769	BOLT	2	M16X2 X 100 Hex Head Cap Screw, Zinc
4	90684	NUT	2	M16 Top Lock, Zinc
3	40361	WASHER	10	M16, Zinc
5	0144061	PLOW BOLT	8	3/8" X 1", Zinc
6	756196	DUST CAP	2	
7	768378	SPACER	2	

756177 Five Hole Swingarm Assembly - Gray




Item No.	Part Number	Part Name	QTY	Remarks
1	756039	BEARING	2	
2		SWINGARM	1	

756178 Five Hole Swingarm Assembly - Green




Item No.	Part Number	Part Name	QTY	Remarks
1	756039	BEARING	2	
2		SWINGARM	1	

756179 Five Hole Swingarm Assembly - Red




Item No.	Part Number	Part Name	QTY	Remarks
1	756039	BEARING	2	
2		SWINGARM	1	

756194 Pivot Bushing




Item No.	Part Number	Part Name	QTY	Remarks
1	756194	BUSHING		

756195 Depth Linkage Spacer




Item No.	Part Number	Part Name	QTY	Remarks
1	756195	SPACER		Only used on assemblies with no sensor installed

756202 Belleville Washer




Item No.	Part Number	Part Name	QTY	Remarks
1	756202	WASHER		

756224 Tail Frame - Gray




Item No.	Part Number	Part Name	QTY	Remarks
1	756224	TAIL FRAME		

756225 Tail Frame - Green




Item No.	Part Number	Part Name	QTY	Remarks
1	756225	TAIL FRAME		

756226 Tail Frame - Red



Item No.	Part Number	Part Name	QTY	Remarks
1	756226	TAIL FRAME		CIH Red

756316 PTC Stem



Item No.	Part Number	Part Name	QTY	Remarks
1	756316	PTC STEM		1/4" O.D. x 1/8" NPT

756237 First Stage Wheel Bearing

