

Technical Bulletin:

Additional Alternator Installation Instructions; connecting Ground and Power



January 27, 2014

Some dealers and customers have asked for greater clarity on which locations to connect the Power and Ground leads onto the alternator when installing vDrive and DeltaForce. This bulletin is simply an addition to help answer those requests and DOES NOT replace the Owners Manual or Installation instructions.

Before beginning the this step of the installation, ensure that there is no power to the alternator. Unplug the power harness running from the tractor battery to the alternator.

1. See the image for 12V+ Power and Ground (Neg -) connection points.

